

Step 1. Attach base to column.



1/4"-20 x 1" long Flat Head Screw
(tighten w/ Philips screw driver)

Step 2. Attach ipad mount to column top.



M10x11mm Set Screw

