

Identify the 39" column to column beam. Attach it to one of the pre-assembled columns using four 1/2" bolts, 2 nuts and six square washers.

Stand up the 2 columns with the 23" section between them and attach this newly assembled piece using four 1/2" bolts, 2 nuts and six square washers. This will create an "ell" shape which will form the rear and side of the closet.



ASSEMBLING MAIN TRUSS STRUCTURE
Install 40.5" beam to column truss section.
Secure to column using four 1/2" bolts, two 1
Secure shackles to beam using 3" long bolts

NOT TO SCALE

Assemble the two 2-piece stringers and hook in place. The right one goes over the top of the column next to the vertical tube. The left one goes over the 40.5" beam app. 3" from where to meet the 184" beam. Start at the bottom and install the slens using 4 carriage bolts with winnuts for each slen.



ASSEMBLY

NOT TO SCALE



NOT TO SCALE

Using two 80.5" sections, attach the end of the beam to a column and install as per the earlier beams and secure using four 1/2" bolts, two 1/2" nuts and six washers.



NOT TO SCALE

ITEM NUMBER	ITEM:	1	REQUIRED
ITEM #	ASSEMBLY 1		

\\ON BRUENCHENHEIN, JOSH - Tuesday, August 09, 2016 11:09:23 AM - C:\USERS\J\BRUENCHENHEIN\DESKTOP\1853601_L1M1853601_DECK.DWG



Install all the joists and rail posts as shown. Make sure to leave bolts for rail posts loose to allow for adjustment. Make sure to position joists as shown in relation to the flat bars welded into the tops of the truss so that the deck beams will center on joist ties. Also position small deck spacers on tubes where shown in red.



CLIENT: LILIN USA

ISC WEST 2016

LOCATION: LAS VEGAS, NV

BOOTH SIZE:	30X30
BOOTH #:	26047

SHOW DATE:
4/6-8/16

ITEM: ASSEMBLY 2

1
REQUIRE

Position the deck boards as shown and secure to structure. Be sure that a joist tube lines up on each front to back seam. Use 6" carriage bolts with 4 hole plates in the middle where 4 boards come together. Use 4" carriage bolts with 2 - hole plates around the perimeter. Leave the wingnuts every those unrails are installed.




After deck boards are installed and loosely secured with hold-downs, install perimeter rails. Sizes are based on top rail length. Position where noted with bottom tabs to the inside. Once this is done and rails are secured, tighten wingnuts on foot hold-downs and large bolts on all rail posts. Then install stair rails. Start at the top and work your way down. Note that there are left and right posts. To identify, note that the rail is offset away from the steps.



NOT TO SCALE

INSTALLING COLUMNS AND BEAM COVERS. First install the upper column covers on top of the deck. If the column covers are new, peel the adhesive backing off the plastic covers and install on the flat bar that is on each rail post spot, 4" from the top. Then install the 63" and 54" column covers making sure that the magnetic cap on the end is towards the bottom. The top should be 18" and 14" from the top of the flat bar when installing. Next, go to the inside column covers. These simply rest on the inside of the posts.

Next, install the lower column covers from downstairs. The procedure is the same, separating the caps. They will go on the upperside of the 3 rail bars welded into the truss. Make sure the double cover of magnet is towards the floor. The 92" column covers go to the outside of the booth. The 96" ones go underneath where beams are attached to the columns.




ASSEMBLY Y

NOT TO SCALE


STANDARD AND ANGLE WALL FRAME ASSEMBLY

The standard wall frames each have 3 holes on the vertical tubes. Align these holes with the holes in the horizontal flat bars welded into the truss columns to mount to the truss and use 5/16" x 1-1/2" bolts with wingnuts to secure. To attach to each other use the same 3 holes and 5/16" x 2-1/2" bolts with wingnuts to attach, when you won't be able to see the column on that side (inside a closet), you can simply remove the column cover. If you will see the side of the wall, but the column cover prevents installation, 1/2" or larger holes are best. The same procedure is used for angle walls, but the hole pattern is different.

Prior to applying the magnetized wall panels on long walls, install a wall to beam bracket in the top of section 2 or 3. This will keep the wall more rigid. Use 2 angle wall brackets to keep the angle wall aligned with the stair stringer. When everything is secure, magnetize your wall panels / graphics to the frames.



STANDARD AND ANGLE WALL FRAME ASSEMBLY




ASSEMBLY

NOT TO SCALE

NEW INFORMATION

To install the ceiling, start by installing all of your track lighting. The two ends simply sit on the lower tube of the beams. Normally, the first one will be app. 2' from the end and the 4' apart. Do all of your electrical work in the ceiling and make sure each track works prior to installing the ceiling panels. Once the electrical work is done, attach an end with a 2" panel and slide it up into place. It sits on top of the lower track tube and covers about half of the 1" track support. Use duct tape in a few places on the edges to secure. Work your way from one end of the beam to the other. When installing 4' panels, install an intermediate support centered on each one. It installs the same as the track lights. Do not use duct tape on each one to keep things from sliding around. One that is done, install the next set of your track lights if you haven't done so already.




ASSEMBLY Y

NOT TO SCALE

NEW INSTRUCTIONS


ASSEMBLY

NOT TO SCALE



ASSEMBLY Y

ASSEMBLY




ASSEMBLY

NOT TO SCALE

ASSEMBLY

NOT TO SCALE

UNDER DECK DOOR NOT TO SCALE

[illegible]

